Master Index

A

addnode utility, *ULTRIX*, 2–7; *OSF/1*, 2–8
Adobe fonts, *SunOS*, 2–11
Alias names, *ULTRIX*, 2–13; *OSF/1*, 2–13; *SunOS*, 2–13; *HP–UX*, 2–11; *AIX*, 2–12; *SCO*, 2–12
Application launcher, *Overview*, 1–3, 1–19; *OpenVMS*, 2–18; *ULTRIX*, 2–28; *OSF/1*, 2–27; *SunOS*, 2–24; *HP–UX*, 2–18; *AIX*, 2–24; *SCO*, 2–22
  DEC OSF/1 AXP systems, *Appendixes*, B–2
  ULTRIX systems, *Appendixes*, B–2
  UNIX systems, *Appendixes*, B–2
Audience
  of this guide, *Overview*, vii

B

Backing up settings
  terminal settings, *Managing*, 3–40
  work group settings, *Managing*, 3–38
Backing up terminals, *Managing*, 3–4
Backup
  OpenVMS system disk, *OpenVMS*, 1–5
Backup icon, *Managing*, 3–5
Backup Terminal dialog box (CM), *Managing*, 3–41
Backup Work Group dialog box (CM), *Managing*, 3–39
BDF font format
  conversion, *OpenVMS*, 2–10
  converting to PCF, *ULTRIX*, 2–11; *OSF/1*, 2–11; *SunOS*, 2–10; *HP–UX*, 2–9; *AIX*, 2–10; *SCO*, 2–10
Bill of materials
  InfoServer system, *InfoServer*, 1–1
BOOT commands, *Appendixes*, A–1
  clearing the booting method, *ULTRIX*, 2–6, 2–7; *OSF/1*, 2–6, 2–8; *Appendixes*, A–2
  displaying the >>> prompt, *Appendixes*, A–1
  entering, *Appendixes*, A–1
BOOT commands (cont'd)
  IP, *ULTRIX*, 2–6; *OSF/1*, 2–6; *SunOS*, 2–7; *HP–UX*, 2–7; *AIX*, 2–8; *SCO*, 2–8
  MOP by file name, *OpenVMS*, 2–7
  MOP by name, *ULTRIX*, 2–7; *OSF/1*, 2–8
  OpenVMS
    MOP by Ethernet address, *OpenVMS*, 2–6
  rebooting the terminal, *Appendixes*, A–3
  VXT software, *Appendixes*, A–1
Booting terminals, *InfoServer*, 2–3; *OpenVMS*, 2–3; *ULTRIX*, 2–3; *OSF/1*, 2–3; *SunOS*, 2–3; *HP–UX*, 2–3; *AIX*, 2–3; *SCO*, 2–3
  creating directories for VXT images, *ULTRIX*, 2–3; *OSF/1*, 2–3; *SunOS*, 2–3; *HP–UX*, 2–3; *AIX*, 2–3; *SCO*, 2–3
  Customize Boot dialog box, *Overview*, 1–13
  error codes, *Appendixes*, A–3
  host-based terminal, *Overview*, 1–9
  MOP, *ULTRIX*, 2–6; *OSF/1*, 2–7
    by Ethernet address, *ULTRIX*, 2–7; *OSF/1*, 2–8
    by VXT image name, *ULTRIX*, 2–6; *OSF/1*, 2–7
    remote node, *ULTRIX*, 2–8; *OSF/1*, 2–9
  overview, *Overview*, 1–2
  remote node, *OpenVMS*, 2–7
  server-based terminal, *Overview*, 1–10
  VXT system image names, *Overview*, 1–12
  with IP, *ULTRIX*, 2–3; *OSF/1*, 2–3; *SunOS*, 2–4; *HP–UX*, 2–4; *AIX*, 2–4; *SCO*, 2–3
bootp command, *ULTRIX*, 2–3; *OSF/1*, 2–4; *SunOS*, 2–4; *HP–UX*, 2–4; *AIX*, 2–4; *SCO*, 2–4
BOOTP daemon, *ULTRIX*, 2–2; *OSF/1*, 2–2; *SunOS*, 2–2; *HP–UX*, 2–2; *AIX*, 2–2; *SCO*, 2–2; *Appendixes*, B–2

BOOTP daemon (cont'd)
creating command entries, *ULTRIX*, 2–3; *OSF/1*, 2–4; *SunOS*, 2–4; *HP–UX*, 2–4; *AIX*, 2–4; *SCO*, 2–4
`/bootpd` file, *SunOS*, 2–6; *HP–UX*, 2–7; *AIX*, 2–7; *SCO*, 2–8
BOOTP/TFTP protocol, *InfoServer*, 2–3
BOOTP/TFTP transport
downloading VXT images, *Overview*, 1–11
BOOTP transport
network access, *Overview*, 1–7
Boot settings
customizing, *Managing*, 3–27
Bridge
effect on VXT loader file, *Overview*, 1–8
BYPASS privilege, *OpenVMS*, 1–2

C

Change Terminal Password dialog box (CM), *Managing*, 3–44
Change Work Group Password dialog box (CM), *Managing*, 3–43
Character cell terminal services, *Overview*, 1–7; *OpenVMS*, 2–15; *ULTRIX*, 2–19; *OSF/1*, 2–19; *SunOS*, 2–19; *HP–UX*, 2–13; *AIX*, 2–19; *SCO*, 2–17
requirements, *Overview*, 1–7
Color
customizing, *Managing*, 2–12
Communication
protocols, *Overview*, 1–2
Composite resource file, *Overview*, 1–3; *Managing*, 2–2
creating, *Managing*, 2–5
Configuration
host system
booting terminals, *ULTRIX*, 2–3, 2–6; *OSF/1*, 2–3, 2–7; *SunOS*, 2–4; *HP–UX*, 2–4; *AIX*, 2–4; *SCO*, 2–3
Configuration management, *Overview*, 1–15, 1–18
Configuration manager, *Managing*, 3–1 to 3–52
compared to host-based resource file, *Managing*, 1–1
Create Font Set dialog box, *Managing*, 3–49
features, *Managing*, 1–1
Font Management dialog box, *Managing*, 3–47
Resource Management dialog box, *Managing*, 3–8
Version 2.1 features, *Managing*, 3–1
Console prompt
entering BOOT commands, *Appendixes*, A–1
Conventions
used in this guide, *Overview*, x
`convertfont` utility, *SunOS*, 2–11
Copy Font Set dialog box (CM), *Managing*, 3–51
Copying
font sets, *Managing*, 3–51
terminal settings, *Managing*, 3–31
work group settings, *Managing*, 3–29
Copy Terminal dialog box (CM), *Managing*, 3–31
Copy Work Group dialog box (CM), *Managing*, 3–29
Create Font Set dialog box (CM), *Managing*, 3–49
Create menu (CM), *Managing*, 3–8, 3–10
creating terminals, *Managing*, 3–12
Create Terminal dialog box (CM), *Managing*, 3–12
Create Work Group dialog box (CM), *Managing*, 3–10
Creating
font sets, *Managing*, 3–49
terminals, *Managing*, 3–12
work groups, *Managing*, 3–10
Cterm
X services, *OpenVMS*, 2–15
Customization file
See Resource file
Customizations, *Overview*, 1–3
host-based terminals, *Overview*, 1–3
server-based terminals, *Overview*, 1–5
Customize AutoStart dialog box, *Overview*, 1–16
Customize Boot dialog box, *Overview*, 1–13
Customize menu (TM)
Font Management dialog box, *Managing*, 3–47
Resource Management dialog box, *Managing*, 3–8
Customize Resource Files dialog box, *Managing*, 2–6
Customize Serial and Parallel Ports dialog box, *OpenVMS*, 2–17
Customize Software Options dialog box, *Overview*, 1–18
Customize Terminal dialog box (CM), *Managing*, 3–23
Customize Work Group dialog box (CM), *Managing*, 3–22
Customizing
terminals, *Managing*, 3–20
work groups, *Managing*, 3–20

Customizing
work groups (cont'd)
Terminal Manager window, *Managing*, 3–24
VXT DECterm window, *Managing*, 3–25
window manager, *Managing*, 3–26

D

Daemon
BOOTP, *ULTRIX*, 2–3; *OSF/1*, 2–4; *SunOS*, 2–4; *HP–UX*, 2–4; *AIX*, 2–4; *SCO*, 2–4
Internet, *ULTRIX*, 2–4; *SunOS*, 2–4; *AIX*, 2–4; *SCO*, 2–4
printer, *ULTRIX*, 2–24; *OSF/1*, 2–22; *SunOS*, 2–21; *HP–UX*, 2–15
system log, *ULTRIX*, 2–4; *OSF/1*, 2–4; *SunOS*, 2–4; *HP–UX*, 2–4
TFTP, *ULTRIX*, 2–4; *OSF/1*, 2–4; *SunOS*, 2–4; *HP–UX*, 2–4
DDS distribution media, *HP–UX*, 1–1, 1–6
DECnet transport, *OpenVMS*, 2–5
customizing terminal settings, *Overview*, 1–18
for a remote installation, *ULTRIX*, 1–9; *OSF/1*, 1–10
for terminal windows, *ULTRIX*, 2–19; *OSF/1*, 2–19
Mirror, *OpenVMS*, 2–14
Network Management Listener, *Overview*, 1–8; *OpenVMS*, 2–14
troubleshooting, *OpenVMS*, 2–14
using, *Managing*, 3–27
VXT$SERVER object, *OpenVMS*, 2–14
X services, *OpenVMS*, 2–12
X sessions
connection logic, *OpenVMS*, 2–13
X session support, *OpenVMS*, 1–12
DEC OSF/1 AXP operating system
character cell terminal services, *OSF/1*, 2–19
DECnet access, *OSF/1*, 2–19
DEC OSF/1 V1.2 Worksystem Software version, *OSF/1*, 1–2
downloading VXT software, *OSF/1*, 2–3
error messages, *Appendixes*, C–1 to C–4
files installed, *Appendixes*, B–1 to B–11
fonts
support requirements, *Overview*, 1–14
hardware requirements, *OSF/1*, 1–2
installing VXT software on, *OSF/1*, 1–1
LAT access, *OSF/1*, 2–19
LAT printer port setup, *OSF/1*, 2–21
local installation
DEC OSF/1 AXP operating system
local installation (cont'd)
from TK50 or magnetic tape, *OSF/1*, 1–8
network requirements, *Overview*, 1–7
print command, *OSF/1*, 2–26
required version, *OSF/1*, 1–1
sample VXT software installation, *OSF/1*, 1–13
system administration checklist, *OSF/1*, 2–1
system management tasks, *OSF/1*, 2–1
TCP/IP printer port setup, *OSF/1*, 2–21
XDMCP support, *OSF/1*, 2–14
DEC OSF/1 worksystem software, *OSF/1*, 1–2
Deleting
work groups and terminals, *Managing*, 3–45
Diagnostics
network, *Overview*, 1–8
Directory
for VXT images, *ULTRIX*, 2–3; *OSF/1*, 2–3; *SunOS*, 2–3; *HP–UX*, 2–3; *AIX*, 2–3; *SCO*, 2–3
Disk space requirements
installation, *InfoServer*, 1–2; *OpenVMS*, 1–4; *ULTRIX*, 1–4; *OSF/1*, 1–5; *SunOS*, 1–4; *HP–UX*, 1–4; *AIX*, 1–4; *SCO*, 1–5
Display color
customizing, *Managing*, 2–12
Display language, *Overview*, 1–19
Documentation, *InfoServer*, 2; *OpenVMS*, 2; *ULTRIX*, 2; *OSF/1*, 2; *SunOS*, 2; *HP–UX*, 2; *AIX*, 2; *SCO*, 2
related documents, *Overview*, ix
Downloading VXT software
methods, *Overview*, 1–11
overview, *Overview*, 1–9

E

Error codes
booting, *Appendixes*, A–3
Error messages
installation
UNIX systems, *Appendixes*, C–1 to C–4
subset installation, *Appendixes*, C–1
Error recovery
IBM AIX system, *AIX*, 1–9
installation, *OpenVMS*, 1–13
Errors
installation, *HP–UX*, 1–10

/etc/bootptab file, *ULTRIX*, 2–4, 2–5; *OSF/1*, 2–4, 2–6; *SunOS*, 2–5; *HP–UX*, 2–5; *AIX*, 2–5; *SCO*, 2–5, 2–8
example, *SunOS*, 2–5; *HP–UX*, 2–5
examples, *ULTRIX*, 2–5; *AIX*, 2–5; *SCO*, 2–5
/etc/exports file, *ULTRIX*, 2–10; *OSF/1*, 2–10; *SunOS*, 2–8; *HP–UX*, 2–8; *AIX*, 2–9; *SCO*, 2–10
/etc/hosts, *ULTRIX*, 2–1; *OSF/1*, 2–1; *AIX*, 2–1; *SCO*, 2–1
/etc/hosts file, *SunOS*, 2–1; *HP–UX*, 2–1
/etc/inetd.conf file, *ULTRIX*, 2–5; *OSF/1*, 2–5
/etc/printcap, *SunOS*, 2–22
/etc/rc2.d/S80lp file, *SCO*, 2–21
/etc/services file, *ULTRIX*, 2–5; *OSF/1*, 2–5; *SunOS*, 2–6; *HP–UX*, 2–7; *AIX*, 2–7; *SCO*, 2–8
Ethernet address
for booting VXT software, *Overview*, 1–11, 1–12; *ULTRIX*, 2–7; *OSF/1*, 2–8

F

Factory-default settings
resetting in memory, *Appendixes*, A–2
File menu (CM), *Managing*, 3–8, 3–14
Find Terminal dialog box, *Managing*, 3–17
Find Work Group dialog box, *Managing*, 3–16
Find Terminal dialog box (CM), *Managing*, 3–17
Find Work Group dialog box (CM), *Managing*, 3–16
fixSunfonts utility, *SunOS*, 2–12
Font, *Overview*, 1–2
access, *Overview*, 1–13, 1–17; *InfoServer*, 2–8; *OpenVMS*, 2–9; *ULTRIX*, 2–9; *OSF/1*, 2–10; *SunOS*, 2–8; *HP–UX*, 2–8; *AIX*, 2–9; *SCO*, 2–9
NFS, *AIX*, 2–10
compilation and conversion, *Overview*, 1–14; *InfoServer*, 2–8
compiling, *OpenVMS*, 2–10
BDF to PCF, *OpenVMS*, 2–10; *ULTRIX*, 2–11; *OSF/1*, 2–11; *SunOS*, 2–10; *HP–UX*, 2–9; *AIX*, 2–10; *SCO*, 2–10
BDF to SNF, *OpenVMS*, 2–10
Sun to BDF, *SunOS*, 2–12
TFTP systems, *ULTRIX*, 2–10, 2–11; *OSF/1*, 2–11; *SunOS*, 2–9; *HP–UX*, 2–9; *AIX*, 2–10; *SCO*, 2–10
conversion
Font
conversion (cont'd)
Sun fonts, *SunOS*, 2–11
convertfont utility, *SunOS*, 2–11
daemon, *OpenVMS*, 2–9
DEC OSF/1 AXP fonts, *OSF/1*, 2–10
fixSunfonts utility, *SunOS*, 2–12
font aliases, *ULTRIX*, 2–13; *OSF/1*, 2–13; *SunOS*, 2–13; *HP–UX*, 2–11; *AIX*, 2–12; *SCO*, 2–12
font path
restricted tftp, *ULTRIX*, 2–9; *SunOS*, 2–8; *HP–UX*, 2–8; *SCO*, 2–9
unrestricted tftp, *ULTRIX*, 2–9; *OSF/1*, 2–10; *SunOS*, 2–8; *HP–UX*, 2–8; *AIX*, 2–9; *SCO*, 2–9
fonts.alias file, *SunOS*, 2–12
font server, *Overview*, 1–17
format
PCF, *OpenVMS*, 2–9; *ULTRIX*, 2–10; *OSF/1*, 2–10; *SunOS*, 2–9; *HP–UX*, 2–9; *AIX*, 2–9; *SCO*, 2–10
SNF, *OpenVMS*, 2–9
Sun fonts, *SunOS*, 2–11
formats supported, *Overview*, 1–13
in VXT kits, *Overview*, 1–14
makeafb utility, *SunOS*, 2–12
management, *ULTRIX*, 2–13; *OSF/1*, 2–12; *SunOS*, 2–13; *HP–UX*, 2–11; *AIX*, 2–11; *SCO*, 2–12
managing, *Managing*, 3–47 to 3–52
requirements, *Overview*, 1–13
Sun Families.list file, *SunOS*, 2–12
ULTRIX fonts, *ULTRIX*, 2–10
UNIX fonts, *ULTRIX*, 2–10; *OSF/1*, 2–10; *SunOS*, 2–9; *HP–UX*, 2–9; *AIX*, 2–9; *SCO*, 2–10
VXT DECterm fonts, *OpenVMS*, 1–20
X11R5 server support, *Overview*, 1–17
XLFD names, *ULTRIX*, 2–13; *OSF/1*, 2–13; *SunOS*, 2–13; *HP–UX*, 2–11; *AIX*, 2–12; *SCO*, 2–12
Font Management dialog box (CM), *Managing*, 3–47
Copy Font Set dialog box, *Managing*, 3–51
Create Font Set dialog box, *Managing*, 3–49
exiting from, *Managing*, 3–52
Font names
listing, *Managing*, 3–47, 3–52
Font paths
NFS, *ULTRIX*, 2–10; *OSF/1*, 2–10; *SunOS*, 2–8; *HP–UX*, 2–8; *AIX*, 2–9; *SCO*, 2–10

Font paths (cont'd)
TFTP, *ULTRIX*, 2–9; *OSF/1*, 2–10; *SunOS*, 2–8; *HP–UX*, 2–8; *AIX*, 2–9; *SCO*, 2–9
`fonts.alias` file, *ULTRIX*, 2–13; *OSF/1*, 2–13; *SunOS*, 2–13; *HP–UX*, 2–11; *AIX*, 2–12; *SCO*, 2–12
Font set
copying, *Managing*, 3–51
creating, *Managing*, 3–49
removing, *Managing*, 3–52
renaming, *Managing*, 3–51
Font set scroll box (CM), *Managing*, 3–47
Font utilities, *ULTRIX*, 2–10, 2–11; *OSF/1*, 2–11; *SunOS*, 2–10; *HP–UX*, 2–9; *AIX*, 2–10; *SCO*, 2–10

H

Halt button
location, *Appendixes*, A–1
Hardware requirements
IBM AIX system, *AIX*, 1–2
installation, *InfoServer*, 1–2; *OpenVMS*, 1–2
SunOS system, *SunOS*, 1–2
Help
installation, *OpenVMS*, 1–5
Hewlett-Packard
See HP–UX system
Host Accessible Printer Port button, *OpenVMS*, 2–17
Host application
launching, *Overview*, 1–19
Host-based image
downloading methods, *Overview*, 1–9
Host-based mode
BOOT commands
VXT EX software, *Appendixes*, A–2
VXT software, *Appendixes*, A–2
Host-based resource file, *Overview*, 1–3, 1–18; *Managing*, 2–1
adding other resources, *Managing*, 2–11
compared to configuration manager, *Managing*, 1–1
composite resource file, *Managing*, 2–5
creating, *Managing*, 2–2
Customize Resource Files dialog box, *Managing*, 2–6
customizing display colors, *Managing*, 2–12
customizing the window manager, *Managing*, 2–11
displaying the list of active files, *Managing*, 2–11
entering comments, *Managing*, 2–3
example, *Managing*, 2–4
Host-based resource file (cont'd)
file name syntax, *Managing*, 2–7
format, *Managing*, 2–1
including other resource files, *Managing*, 2–4
specifying, *Managing*, 2–6
substitute characters, *Managing*, 2–8
syntax, *Managing*, 2–3
template, *Managing*, 2–1, 2–2, 2–13
Host-based system
configuration, *Overview*, 1–3
overview, *Overview*, 1–3
Host-based terminal, *Managing*, 3–6
change password, *Managing*, 3–44
choosing for configuration, *Managing*, 3–14
configuration manager, *Managing*, 3–6
terminal password, *Managing*, 3–7
finding for configuration, *Managing*, 3–16
host-based resource files, *Managing*, 2–1
managing, *Managing*, 1–3
Host-based VXT software
booting, *InfoServer*, 2–5
HP–UX operating system
character cell terminal services, *HP–UX*, 2–13
downloading VXT software, *HP–UX*, 2–3
error messages, *Appendixes*, C–1 to C–4
files installed, *Appendixes*, B–1 to B–11
fonts
support requirements, *Overview*, 1–14
hardware requirements, *HP–UX*, 1–2
installing VXT software on, *HP–UX*, 1–1 to 1–17
local installation
from DDS or magnetic tape, *HP–UX*, 1–7
network requirements, *Overview*, 1–7
print command, *HP–UX*, 2–17
required version, *HP–UX*, 1–1
sample VXT software installation, *HP–UX*, 1–10
software requirements, *HP–UX*, 1–2
system administration checklist, *HP–UX*, 2–1
system management tasks, *HP–UX*, 2–1
TCP/IP printer port setup, *HP–UX*, 2–15

I

IBM AIX operating system
character cell terminal services, *AIX*, 2–19
downloading VXT software, *AIX*, 2–3
error messages, *Appendixes*, C–1 to C–4
error recovery, *AIX*, 1–9
files installed, *Appendixes*, B–1 to B–11
fonts

IBM AIX operating system
fonts (cont'd)
support requirements, *Overview*, 1–14
installing VXT software on, *AIX*, 1–1 to 1–16
local installation
from QIC 24 or magnetic tape, *AIX*, 1–7
network requirements, *Overview*, 1–7
print command, *AIX*, 2–23
required version, *AIX*, 1–1
sample VXT software installation, *AIX*, 1–10
software requirements, *AIX*, 1–2
system administration checklist, *AIX*, 2–1
system management tasks, *AIX*, 2–1
TCP/IP printer port setup, *AIX*, 2–21
XDMCP support, *AIX*, 2–13
Icon
backup, *Managing*, 3–5, 3–38
backup terminal, *Managing*, 3–8
backup work group, *Managing*, 3–8
server, *Managing*, 3–8
terminal, *Managing*, 3–8
work group, *Managing*, 3–8
Images
See System images
`inetd.conf` file, *ULTRIX*, 2–3; *OSF/1*, 2–4; *SunOS*, 2–4; *HP–UX*, 2–4; *AIX*, 2–4; *SCO*, 2–4
InfoReader library
files, *InfoServer*, 1–5, 1–8
online documents, *Overview*, 1–17
InfoServer operating system
accessing, *InfoServer*, 2–2
booting terminals by Ethernet address, *InfoServer*, 2–5
commands
CREATE SERVICE, *InfoServer*, 2–6
SET SERVER MOP ENABLED, *InfoServer*, 2–6
SET SERVER REMOTE DEVICES, *InfoServer*, 2–12
SHOW SERVER, *InfoServer*, 2–11
UPDATE VXT, *InfoServer*, 2–5, 2–9
configuration, *Overview*, 1–4
controlling file creation on, *InfoServer*, 2–11
disk space requirements, *InfoServer*, 1–2
downloading VXT software, *InfoServer*, 2–3
enabling remote devices, *InfoServer*, 2–12
finding services, *Managing*, 3–18
font access, *InfoServer*, 2–8
fonts
compiling, *InfoServer*, 2–8
support requirements, *Overview*, 1–14
InfoServer operating system (cont'd)
hardware requirements, *InfoServer*, 1–2
installing VXT software, *InfoServer*, 1–1
LASTport/Disk transport, *InfoServer*, 2–3
LASTport group code, *Managing*, 3–2
loading host-based VXT software, *InfoServer*, 2–5
loading VXT versions, *InfoServer*, 2–4
management tasks, *InfoServer*, 2–1
MOP-filtering bridge, *InfoServer*, 2–3
network requirements, *Overview*, 1–7
paged memory requirements, *InfoServer*, 2–11
paging files, *InfoServer*, 2–11
password, *InfoServer*, 1–3, 2–9
purging VXT versions, *InfoServer*, 2–7
Remote Device List, *InfoServer*, 2–11
SHOW PARTITION command, *InfoServer*, 1–2, 1–6
software requirements, *InfoServer*, 1–2
UPDATE VXT command, *InfoServer*, 1–3
VXT loader file, *InfoServer*, 2–3
Installation, *InfoServer*, 1–1; *OpenVMS*, 1–1; *ULTRIX*, 1–1; *OSF/1*, 1–1; *SunOS*, 1–1; *HP–UX*, 1–1; *AIX*, 1–1; *SCO*, 1–1
error recovery, *ULTRIX*, 1–10; *OSF/1*, 1–11; *SunOS*, 1–9; *HP–UX*, 1–9; *SCO*, 1–9
files installed
for InfoServer system, *InfoServer*, 1–8
for OpenVMS system, *OpenVMS*, 1–19
for UNIX systems, *Appendixes*, B–1 to B–11
installation time, *InfoServer*, 1–1; *OpenVMS*, 1–1; *ULTRIX*, 1–2; *OSF/1*, 1–2; *SunOS*, 1–2; *HP–UX*, 1–2; *AIX*, 1–2; *SCO*, 1–2
local, *ULTRIX*, 1–7; *OSF/1*, 1–8; *SunOS*, 1–7; *HP–UX*, 1–7; *AIX*, 1–7; *SCO*, 1–7
new features, *Overview*, 1–17
remote, *ULTRIX*, 1–8; *OSF/1*, 1–9; *SunOS*, 1–8; *HP–UX*, 1–8; *AIX*, 1–8
sample session, *ULTRIX*, 1–11; *OSF/1*, 1–13; *SunOS*, 1–11; *HP–UX*, 1–10; *AIX*, 1–10; *SCO*, 1–11
for InfoServer system, *InfoServer*, 1–7
for OpenVMS AXP system, *OpenVMS*, 1–15
software requirements, *InfoServer*, 1–2
Installation verification procedure
error recovery, *OpenVMS*, 1–13
running separately, *OpenVMS*, 1–14

instvxtfonts utility, *ULTRIX*, 2–12; *OSF/1*, 2–12; *SunOS*, 2–10; *HP–UX*, 2–10; *AIX*, 2–11; *SCO*, 2–11
Internet daemon, *ULTRIX*, 2–2, 2–4; *OSF/1*, 2–2; *SunOS*, 2–2, 2–4; *HP–UX*, 2–2; *AIX*, 2–2, 2–4; *SCO*, 2–2, 2–4
  restarting, *ULTRIX*, 2–5; *OSF/1*, 2–6; *SunOS*, 2–7; *HP–UX*, 2–7; *AIX*, 2–7; *SCO*, 2–8
IP transport
  in default booting sequence, *Overview*, 1–12
  loading VXT software, *ULTRIX*, 2–3; *OSF/1*, 2–3; *SunOS*, 2–4; *HP–UX*, 2–4; *AIX*, 2–4; *SCO*, 2–3
    directories, *ULTRIX*, 2–3; *OSF/1*, 2–3; *SunOS*, 2–3; *HP–UX*, 2–3; *AIX*, 2–3; *SCO*, 2–3
  VXT boot commands, *ULTRIX*, 2–6; *OSF/1*, 2–6; *SunOS*, 2–7; *HP–UX*, 2–7; *AIX*, 2–8; *SCO*, 2–8
IVP
  See Installation verification procedure, *OpenVMS*, 1–13

K

Keyboard
  Sun style, *Overview*, 1–19
Key name, in resource file, *Managing*, 2–5

L

LAN bridge, *InfoServer*, 2–3
LASTport/Disk transport, *Overview*, 1–5; *InfoServer*, 2–3
  font access, *Overview*, 1–6
  network access, *Overview*, 1–7
LASTport group code, *Overview*, 1–18; *InfoServer*, 2–13; *Managing*, 3–2
  customizing, *Managing*, 3–27
LASTport Group Code (CM), *Managing*, 3–14
LATCP file, *OpenVMS*, 2–20
LAT font daemon, *OpenVMS*, 2–9
LAT/Master
  for OpenVMS operating system, *InfoServer*, 1–2
  for OpenVMS systems, *OpenVMS*, 2–20
LAT printer port, *OSF/1*, 2–21
  OpenVMS setup, *OpenVMS*, 2–17
  ULTRIX setup, *ULTRIX*, 2–21
LAT protocol
  specifying font sets, *Managing*, 3–50
LAT responder, *Overview*, 1–8; *InfoServer*, 2–12
LAT service responder
  for OpenVMS systems, *OpenVMS*, 2–20
LAT transport
  font access, *OpenVMS*, 2–9
  for terminal windows, *ULTRIX*, 2–19; *OSF/1*, 2–19
  network access, *Overview*, 1–7
  X services, *OpenVMS*, 2–11
Launching applications, *Overview*, 1–3
Loading VXT software
  See Booting
  See Booting terminals
Local installation, *ULTRIX*, 1–7; *OSF/1*, 1–8; *SunOS*, 1–7; *HP–UX*, 1–7; *AIX*, 1–7; *SCO*, 1–7
  for SunOS
    from QIC 24 or magnetic tape, *SunOS*, 1–7
Local Terminals server, *Managing*, 3–6
Local work group, *Managing*, 3–6
Locking
  customized settings, *Managing*, 3–22, 3–24
  DECterm settings, *Managing*, 3–25
  window manager settings, *Managing*, 3–26
Log file, *ULTRIX*, 2–4; *OSF/1*, 2–4; *SunOS*, 2–4; *AIX*, 2–4; *SCO*, 2–4
lpadmin command, *HP–UX*, 2–16; *SCO*, 2–20, 2–21
lp command, *HP–UX*, 2–17
lpr command, *ULTRIX*, 2–27; *OSF/1*, 2–26; *SunOS*, 2–23; *AIX*, 2–23
lprsetup command, *ULTRIX*, 2–22, 2–25; *OSF/1*, 2–23

M

Maintenance menu (CM), *Managing*, 3–9, 3–43, 3–44
makeafb utility, *SunOS*, 2–12
Managing
  fonts, *Managing*, 3–47 to 3–52
  server-based terminals, *Managing*, 3–2
  terminals, *Managing*, 3–8 to 3–46
    configuration manager, *Managing*, 3–1
    host-based resource files, *Managing*, 2–1
    overview, *Managing*, 1–1
  work groups, *Managing*, 3–8 to 3–46
man pages, *SunOS*, 2–7
Media software distribution kit
  for InfoServer system, *InfoServer*, 1–1

Memory
effect of network protocols, *Overview*, 1–7
resetting VXT factory-default settings, *Appendixes*, A–2
mkfontdir utility, *ULTRIX*, 2–10; *OSF/1*, 2–11; *SunOS*, 2–9; *HP–UX*, 2–9; *AIX*, 2–10; *SCO*, 2–10
mkvxtfonts utility, *ULTRIX*, 2–12; *OSF/1*, 2–12; *SunOS*, 2–10; *HP–UX*, 2–10; *AIX*, 2–11; *SCO*, 2–11
MOM$LOAD search list, *OpenVMS*, 2–6
MOP transport
booting terminals
by Ethernet address, *OpenVMS*, 2–5; *ULTRIX*, 2–7; *OSF/1*, 2–8
by VXT image name, *OpenVMS*, 2–6; *ULTRIX*, 2–6; *OSF/1*, 2–7
troubleshooting, *ULTRIX*, 2–8
booting terminals by Ethernet address, *InfoServer*, 2–5, 2–6
downloading VXT images, *Overview*, 1–11
enabling, *InfoServer*, 2–5
in default booting sequence, *Overview*, 1–11
loading VXT software, *ULTRIX*, 2–6; *OSF/1*, 2–7
directories, *ULTRIX*, 2–3; *OSF/1*, 2–3
MOP-filtering bridge, *InfoServer*, 2–3
network bridges and VXT loader file, *Overview*, 1–8
troubleshooting MOP loading, *OSF/1*, 2–8
VXT loader file, *InfoServer*, 2–3
MOP trigger, *OpenVMS*, 2–7
booting terminals, *ULTRIX*, 2–8; *OSF/1*, 2–9
mop_mom listener, *ULTRIX*, 2–6; *OSF/1*, 2–7
Move Terminals dialog box (CM), *Managing*, 3–34
.mwmrc file
effect on VXT Create pop-up menu, *Managing*, 2–12
.mwmrc file, *Managing*, 2–11

N

Naming conventions
system image, *Overview*, 1–12
Native resource file, *Overview*, 1–3; *Managing*, 1–1
definition, *Managing*, 3–3
NCP commands
to configure terminals, *OpenVMS*, 2–5
Network
configuration
host-based, *Overview*, 1–3
Networks
bridges, *Overview*, 1–8
configuration
server-based, *Overview*, 1–4
diagnostic tools, *Overview*, 1–8
management overview, *Overview*, 1–1
protocol management, *Overview*, 1–2, 1–6, 1–7
protocol requirements, *Overview*, 1–6
NeWS bitmap fonts, *SunOS*, 2–11
NFS transport, *Overview*, 1–17
font access, *Overview*, 1–6, 1–17; *AIX*, 2–10
font paths, *ULTRIX*, 2–10; *OSF/1*, 2–10; *SunOS*, 2–8; *HP–UX*, 2–8; *AIX*, 2–9; *SCO*, 2–10
terminal customizations, *Overview*, 1–7
NIS server, *SunOS*, 2–6; *AIX*, 2–7
NML object
DECnet transport, *OpenVMS*, 2–14
NVRAM
synchronizing settings in, *Managing*, 3–27
NVR-based terminals, *Managing*, 3–6

O

Online documents, *Overview*, 1–17
OpenVMS Authorize Utility, *OpenVMS*, 1–4
OpenVMS operating system
booting terminals
MOP by VXT image name, *OpenVMS*, 2–6
MOP trigger, *OpenVMS*, 2–7
remote node, *OpenVMS*, 2–7
character cell terminal services, *OpenVMS*, 2–15
DECnet transport
system addresses, *OpenVMS*, 2–13
downloading VXT software, *OpenVMS*, 2–3
error recovery, *OpenVMS*, 1–13
fonts
access, *OpenVMS*, 2–9
compilation and conversion, *OpenVMS*, 2–10
support requirements, *Overview*, 1–14
hardware requirements, *OpenVMS*, 1–2
installation procedure, *OpenVMS*, 1–5
installing VXT software on, *OpenVMS*, 1–1
LAT/Master, *OpenVMS*, 2–20
LAT printer port setup, *OpenVMS*, 2–17
LAT services, *OpenVMS*, 2–11
management tasks, *OpenVMS*, 2–1
MOP
booting terminals

OpenVMS operating system
MOP
booting terminals (cont'd)
MOP by Ethernet address, *OpenVMS*, 2–5
network requirements, *Overview*, 1–7
paged memory requirements, *OpenVMS*, 2–20
postinstallation steps, *OpenVMS*, 2–1
print command, *OpenVMS*, 2–17
process account limits and quotas, *OpenVMS*, 1–4
required version, *OpenVMS*, 1–1
software requirements, *OpenVMS*, 1–2
system administration checklist, *OpenVMS*, 2–1
system disk backup, *OpenVMS*, 1–5
system parameters, *OpenVMS*, 1–4
system startup file, *OpenVMS*, 2–3
terminal customizations, *OpenVMS*, 2–16
VT1300 booting, *OpenVMS*, 2–7
VT1300 terminal, *OpenVMS*, 2–13
X services, *OpenVMS*, 2–11
XTDRIVER, *OpenVMS*, 2–11
OpenVMS operating systems
VXT software
CD–ROM, *OpenVMS*, 1–23
Options menu (CM), *Managing*, 3–9
Organization
of this guide, *Overview*, viii
Overview, VXT software
downloading VXT software, *Overview*, 1–9
font access, *Overview*, 1–13
font compilation and conversion, *Overview*, 1–14
fonts provided, *Overview*, 1–14
host requirements, *Overview*, 1–6
network protocols, *Overview*, 1–6
terminal customizations, *Overview*, 1–15
using protocols, *Overview*, 1–7
using VXT DECterm, *Overview*, 1–7
X session support, *Overview*, 1–7

P

Paged memory requirements, *InfoServer*, 2–11
Paging files
allocation, *InfoServer*, 2–11
reclaiming, *InfoServer*, 2–12
Partition names, *InfoServer*, 2–6
Password
for InfoServer services, *InfoServer*, 2–9
host-based terminals, *Managing*, 3–7
InfoServer system, *InfoServer*, 1–3
MOP trigger, *ULTRIX*, 2–8; *OSF/1*, 2–9
VXT$SERVER account, *OpenVMS*, 1–12
Password (cont'd)
VXT manager password, *InfoServer*, 1–4; *Managing*, 3–3
changing, *InfoServer*, 2–9
work group
changing, *InfoServer*, 2–10
work groups, *Managing*, 3–43, 3–44
Password dialog box (CM)
for backing up a terminal, *Managing*, 3–42
for backing up a work group, *Managing*, 3–40
for copying a work group, *Managing*, 3–30
for copying terminals, *Managing*, 3–32
for creating terminals, *Managing*, 3–13
for customizing host-based terminals, *Managing*, 3–21
for customizing server-based terminals, *Managing*, 3–21
for customizing work groups, *Managing*, 3–21
for deleting a work group, *Managing*, 3–45
for moving terminals, *Managing*, 3–36
for removing fonts, *Managing*, 3–52
VXT manager password, *Managing*, 3–11
PCF font format, *ULTRIX*, 2–10; *OSF/1*, 2–10; *SunOS*, 2–9; *HP–UX*, 2–9; *AIX*, 2–9; *SCO*, 2–10
Power-up sequence, *Overview*, 1–11
Prevent User Customization button (CM), *Managing*, 3–22
PRINT command, *OpenVMS*, 2–17
Printer port
LAT, *OSF/1*, 2–21
setup, *ULTRIX*, 2–21
OpenVMS system, *OpenVMS*, 2–17
TCP/IP, *ULTRIX*, 2–23; *OSF/1*, 2–21; *SunOS*, 2–21; *HP–UX*, 2–15; *AIX*, 2–21; *SCO*, 2–19
creating printers, *ULTRIX*, 2–25; *OSF/1*, 2–23; *SunOS*, 2–22; *HP–UX*, 2–16; *AIX*, 2–22; *SCO*, 2–20
setting up printers, *ULTRIX*, 2–25; *OSF/1*, 2–23; *SunOS*, 2–22; *HP–UX*, 2–16; *SCO*, 2–20
terminal settings, *OpenVMS*, 2–17; *ULTRIX*, 2–23, 2–27; *OSF/1*, 2–25; *SunOS*, 2–23; *HP–UX*, 2–17; *AIX*, 2–23; *SCO*, 2–21
Printer support utilities
DEC OSF/1 AXP systems, *Appendixes*, B–3
ULTRIX systems, *Appendixes*, B–3
UNIX systems, *Appendixes*, B–3

Printing
from host systems, *Overview*, 1–3
from the host, *OpenVMS*, 2–17; *ULTRIX*, 2–27; *OSF/1*, 2–26; *SunOS*, 2–23; *HP–UX*, 2–17; *AIX*, 2–23; *SCO*, 2–21
`vxtlpd` printer daemon, *ULTRIX*, 2–23; *OSF/1*, 2–21; *SunOS*, 2–21; *HP–UX*, 2–15; *AIX*, 2–21; *SCO*, 2–19
Problems
installation, *HP–UX*, 1–10
Process account limits and quotas
for OpenVMS system, *OpenVMS*, 1–4
Protocols, *Overview*, 1–6
requirements
booting VXT software, *Overview*, 1–11

R

Read-only terminal, *Managing*, 3–3, 3–22
Unregistered Terminals work group, *Managing*, 3–4
Rebooting, *Appendixes*, A–3
Remote applications
starting, *OpenVMS*, 2–18; *ULTRIX*, 2–28; *OSF/1*, 2–27; *SunOS*, 2–24; *HP–UX*, 2–18; *AIX*, 2–24; *SCO*, 2–22
Remote Device List, *InfoServer*, 2–11
Remote installation, *ULTRIX*, 1–8; *OSF/1*, 1–9; *SunOS*, 1–8; *HP–UX*, 1–8; *AIX*, 1–8
for SCO ODT system, *SCO*, 1–8
from a `tar` file, *SCO*, 1–8
Resource file, *Overview*, 1–3, 1–18
See also Host-based resource file, Native resource file.
See also Native resource file, Host-based resource file
host-based, *Managing*, 1–1
new terminals, *Managing*, 2–11
overview, *Overview*, 1–15
Xrm syntax, *Managing*, 2–1
Resource Management dialog box (CM), *Managing*, 3–8
Backup Terminal dialog box, *Managing*, 3–41
Backup Work Group dialog box, *Managing*, 3–39
Change Terminal Password dialog box, *Managing*, 3–44
Change Work Group Password dialog box, *Managing*, 3–43
choosing a work group or terminal in, *Managing*, 3–14
Copy Terminal dialog box, *Managing*, 3–31
Resource Management dialog box (CM) (cont'd)
Copy Work Group dialog box, *Managing*, 3–29
Create menu, *Managing*, 3–8, 3–10
Create Terminal dialog box, *Managing*, 3–12
Customize Terminal dialog box, *Managing*, 3–23
Customize Work Group dialog box, *Managing*, 3–22
displaying servers by group code, *Managing*, 3–14
File menu, *Managing*, 3–8, 3–14
finding a work group or terminal, *Managing*, 3–16
finding terminals, *Managing*, 3–17
finding work groups, *Managing*, 3–16
Maintenance menu, *Managing*, 3–9, 3–43, 3–44
Move Terminals dialog box, *Managing*, 3–34
Options menu, *Managing*, 3–1, 3–9
scroll box, *Managing*, 3–8
Synchronize NVRAM dialog box, *Managing*, 3–27
updating the list of servers, *Managing*, 3–14
Resource Management window
exiting from, *Managing*, 3–46
Restricted mode
`tftp` daemon, *ULTRIX*, 2–4, 2–9; *OSF/1*, 2–4; *SunOS*, 2–4, 2–8; *HP–UX*, 2–4, 2–8; *SCO*, 2–4, 2–9
`rgb.txt` file, *Managing*, 2–12
`rm-vxt-kit` utility, *Appendixes*, B–1

S

SCO ODT operating system
character cell terminal services, *SCO*, 2–17
downloading VXT software, *SCO*, 2–3
error messages, *Appendixes*, C–1 to C–4
files installed, *Appendixes*, B–1 to B–11
fonts
support requirements, *Overview*, 1–14
hardware requirements, *SCO*, 1–2
installing VXT software on, *SCO*, 1–1 to 1–17
local installation
from QIC 24 or magnetic tape, *SCO*, 1–7
network requirements, *Overview*, 1–7
print command, *SCO*, 2–21
remote installation, *SCO*, 1–8
from a `tar` file, *SCO*, 1–8

SCO ODT operating system (cont'd)
required version, *SCO*, 1–1
sample VXT software installation, *SCO*, 1–11
software requirements, *SCO*, 1–2
system management tasks, *SCO*, 2–1
TCP/IP printer port setup, *SCO*, 2–19
XDMCP support, *SCO*, 2–13
Server-based image
downloading methods, *Overview*, 1–10
Server-based mode
BOOT commands
VXT EX software, *Appendixes*, A–2
VXT software, *Appendixes*, A–2
Server-based systems
configuration, *Overview*, 1–4
overview, *Overview*, 1–4
Server-based terminal
adding to a work group, *Managing*, 3–12
choosing for configuration, *Managing*, 3–14
configuration manager, *Managing*, 3–2
finding for configuration, *Managing*, 3–16
host-based resource files, *Managing*, 2–1
LASTport group code, *Managing*, 3–2
managing, *Managing*, 1–5
work group, *Managing*, 3–10
Servers
updating the list of, *Managing*, 3–14
Service names, *Overview*, 1–12
SETPRV, *OpenVMS*, 1–2
SET SERVER LASTPORT GROUP, *Managing*, 3–2
`smit` utility, *AIX*, 2–22
SNF font format, *OpenVMS*, 2–10
SNMP diagnostic tool, *Overview*, 1–8
Software Options dialog box, *Overview*, 1–17
Software requirements
installation, *InfoServer*, 1–2; *OpenVMS*, 1–2
Software subsets, *ULTRIX*, 1–3; *OSF/1*, 1–3; *SunOS*, 1–3; *HP–UX*, 1–3; *AIX*, 1–3; *SCO*, 1–3
error messages, *Appendixes*, C–1
Startup menu item, *Overview*, 1–18
Status messages
installation
UNIX systems, *Appendixes*, C–3
Sun fonts
conversion kit, *Appendixes*, B–11
Sun OpenWindows
`mkfontdir` utility, *SunOS*, 2–9
SunOS operating system
character cell terminal services, *SunOS*, 2–19
downloading VXT software, *SunOS*, 2–3
error messages, *Appendixes*, C–1 to C–4
SunOS operating system (cont'd)
files installed, *Appendixes*, B–1 to B–11
font conversion, *SunOS*, 2–11
fonts
support requirements, *Overview*, 1–14
installing VXT software on, *SunOS*, 1–1 to 1–18
keyboard, *Overview*, 1–19
local installation
from a `tar` file, *SunOS*, 1–7
from QIC 24 or magnetic tape, *SunOS*, 1–7
network requirements, *Overview*, 1–7
print command, *SunOS*, 2–23
required version, *SunOS*, 1–1
sample VXT installation, *SunOS*, 1–11
software requirements, *SunOS*, 1–2
system administration checklist, *SunOS*, 2–1
system management tasks, *SunOS*, 2–1
TCP/IP printer port setup, *SunOS*, 2–21
XDMCP support, *SunOS*, 2–14
Support server
copying, *Managing*, 3–51
Synchronize NVRAM dialog box, *Managing*, 3–27
SYSPRV, *OpenVMS*, 1–2
System administration checklist, *OpenVMS*, 2–1; *ULTRIX*, 2–1; *OSF/1*, 2–1; *SunOS*, 2–1; *HP–UX*, 2–1; *AIX*, 2–1; *SCO*, 2–1
System backup
OpenVMS system, *OpenVMS*, 1–5
System images, *ULTRIX*, 2–3; *OSF/1*, 2–3; *SunOS*, 2–3; *HP–UX*, 2–3; *AIX*, 2–3; *SCO*, 2–3
DEC OSF/1 AXP systems, *Appendixes*, B–2
installation choices, *OpenVMS*, 1–3; *ULTRIX*, 1–4; *OSF/1*, 1–4; *SunOS*, 1–4; *HP–UX*, 1–4; *AIX*, 1–4; *SCO*, 1–4
naming conventions, *Overview*, 1–12
service names, *InfoServer*, 2–6
ULTRIX systems, *Appendixes*, B–2
UNIX systems, *Appendixes*, B–2
System log file, *ULTRIX*, 2–4; *OSF/1*, 2–4; *SunOS*, 2–4; *AIX*, 2–4; *SCO*, 2–4
System parameters
OpenVMS system, *OpenVMS*, 1–4

T

TCP/IP printer port, *OSF/1*, 2–21; *AIX*, 2–21; *SCO*, 2–19
  HP–UX setup, *HP–UX*, 2–15
  SunOS setup, *SunOS*, 2–21
  ULTRIX setup, *ULTRIX*, 2–23
TCP/IP transport
  font access, *Overview*, 1–17
  for a remote installation, *ULTRIX*, 1–8; *OSF/1*, 1–9; *SunOS*, 1–8; *HP–UX*, 1–8; *AIX*, 1–8; *SCO*, 1–8
  X services, *OpenVMS*, 2–12, 2–15
Telnet transport
  providing access to, *ULTRIX*, 2–19; *OSF/1*, 2–19; *SunOS*, 2–19; *HP–UX*, 2–13; *AIX*, 2–19; *SCO*, 2–17
Terminal customization files
  service ratings, *Managing*, 3–38
Terminal customizations
  DEC OSF/1 AXP system, *OSF/1*, 2–20
  HP–UX system, *HP–UX*, 2–14
  IBM AIX system, *AIX*, 2–20
  SCO ODT system, *SCO*, 2–18
  SunOS system, *SunOS*, 2–20
  ULTRIX system, *ULTRIX*, 2–20
Terminal emulation, *Overview*, 1–7
Terminal Manager window
  customizing
    for work groups, *Managing*, 3–24
  locking settings
    for a work group, *Managing*, 3–24
Terminal resource file, *Overview*, 1–3
Terminals, managing, *Managing*, 3–8 to 3–46
  backing up, *Managing*, 3–4
  backing up customized settings, *Managing*, 3–40
  choosing a server for, *Managing*, 3–13
  choosing a work group for, *Managing*, 3–13
  copying customized settings, *Managing*, 3–31
  customizing, *Managing*, 3–20
  customizing from the Configuration Manager, *Managing*, 3–24
  deleting, *Managing*, 3–45
  getting started with work groups, *Managing*, 3–2
  locking customized settings, *Managing*, 3–24
  locking DECterm settings, *Managing*, 3–25
  locking window manager settings, *Managing*, 3–26
Terminals, managing (cont'd)
  moving among work groups, *Managing*, 3–34
  using work group settings, *Managing*, 3–23
Terminal window session, *Overview*, 1–1
TFTP
  specifying font sets, *Managing*, 3–50
`tftp` command, *ULTRIX*, 2–3; *OSF/1*, 2–4; *SunOS*, 2–4; *HP–UX*, 2–4; *AIX*, 2–4; *SCO*, 2–4
`tftp` daemon
  restricted mode, *SunOS*, 2–4; *SCO*, 2–4
    font paths, *ULTRIX*, 2–9; *SunOS*, 2–8; *HP–UX*, 2–8; *SCO*, 2–9
  unrestricted mode, *ULTRIX*, 2–9; *OSF/1*, 2–10; *SunOS*, 2–8; *HP–UX*, 2–8; *AIX*, 2–9; *SCO*, 2–9
TFTP daemon
  restricted mode, *ULTRIX*, 2–4; *OSF/1*, 2–4; *HP–UX*, 2–4
TFTP transport
  font access, *Overview*, 1–6
  font paths, *ULTRIX*, 2–9; *OSF/1*, 2–10; *SunOS*, 2–8; *HP–UX*, 2–8; *AIX*, 2–9; *SCO*, 2–9
  network access
    terminal customizations, *Overview*, 1–7
`touch` command, *ULTRIX*, 2–15; *OSF/1*, 2–15; *SunOS*, 2–15; *AIX*, 2–15
Transport protocols, *Overview*, 1–6
Troubleshooting
  booting error codes, *Appendixes*, A–3
  clearing nonvolatile RAM, *Appendixes*, A–2
  DECnet transport, *OpenVMS*, 2–14
  entering boot commands, *Appendixes*, A–1
  MOP, *ULTRIX*, 2–8; *OSF/1*, 2–8
  network diagnostic facilities, *Overview*, 1–8
`tty`
  making available, *ULTRIX*, 2–22
  selecting, *ULTRIX*, 2–21

U

ULTRIX
  system administration checklist, *ULTRIX*, 2–1
ULTRIX operating system
  character cell terminal services, *ULTRIX*, 2–19
  DECnet access, *ULTRIX*, 2–19
  downloading VXT software, *ULTRIX*, 2–3
  error messages, *Appendixes*, C–1 to C–4
  files installed, *Appendixes*, B–1 to B–11

ULTRIX operating system (cont'd)
fonts
support requirements, *Overview*, 1–14
hardware requirements, *ULTRIX*, 1–2
installing VXT software on, *ULTRIX*, 1–1 to 1–17
LAT access, *ULTRIX*, 2–19
LAT printer port setup, *ULTRIX*, 2–21
local installation
from TK50 or magnetic tape, *ULTRIX*, 1–7
management tasks, *ULTRIX*, 2–1
network requirements, *Overview*, 1–7
print command, *ULTRIX*, 2–27
printer port setup, *ULTRIX*, 2–23
required version, *ULTRIX*, 1–1
sample VXT software installation, *ULTRIX*, 1–11
software requirements, *ULTRIX*, 1–2
TCP/IP printer port setup, *ULTRIX*, 2–23
XDMCP support, *ULTRIX*, 2–14
Unlocking
customized settings, *Managing*, 3–24
DECterm settings, *Managing*, 3–25
window manager settings, *Managing*, 3–26
Unregistered Terminals work group, *Managing*, 3–3
Unrestricted mode
`tftp` daemon, *ULTRIX*, 2–9; *OSF/1*, 2–10; *SunOS*, 2–8; *HP–UX*, 2–8; *AIX*, 2–9; *SCO*, 2–9
Update Known Servers (CM), *Managing*, 3–14
Upgrading VXT software
InfoServer system, *InfoServer*, 2–4
`/usr/lib/X11/xdm` directory, *OSF/1*, 2–14
UWS software
required version, *ULTRIX*, 1–1

V

VAXcluster support, *OpenVMS*, 2–3
VMSINSTAL, *OpenVMS*, 1–2
requirements, *OpenVMS*, 1–5
VMS system
See OpenVMS operating system
VT1300 terminal, *Overview*, 1–16; *OpenVMS*, 2–7
booting, *OpenVMS*, 2–7; *Appendixes*, A–1
EWS$SERVER, *OpenVMS*, 2–12
loading VXT software, *InfoServer*, 2–6
`vuelogin` utility (HP–UX), *HP–UX*, 2–12
VXT$BOOT_BY_NAME, *OpenVMS*, 2–3, 2–6
VXT$INSTALL_STARTLOGIN, *OpenVMS*, 2–4
VXT$INSTALL_WSA, *OpenVMS*, 2–4
VXT$LIBRARY_PATH, *OpenVMS*, 2–3
VXT$SERVER.COM file, *OpenVMS*, 2–12
VXT$SERVER account, *OpenVMS*, 1–12
VXT$STARTUP.COM
customizing, *OpenVMS*, 2–3
VXT$STARTUP.COM file, *OpenVMS*, 2–3
VXT 2000 windowing terminal
PCF font format, *ULTRIX*, 2–10; *OSF/1*, 2–10; *SunOS*, 2–9; *HP–UX*, 2–9; *AIX*, 2–9; *SCO*, 2–10
`vxtcfgtmpl.xrm` resource file, *Managing*, 2–1
VXT Create pop-up menu
effected by window manager file, *Managing*, 2–12
VXT DECterm windows
locking settings
for a work group, *Managing*, 3–25
overview, *Overview*, 1–7
VXT EX software, *Overview*, 1–2
service names, *InfoServer*, 2–6
VXT font manager, *InfoServer*, 2–8
VXTLDR.SYS, *InfoServer*, 2–3
`vxtldr` image, *ULTRIX*, 1–4; *OSF/1*, 1–5; *SunOS*, 1–4; *HP–UX*, 1–4; *AIX*, 1–4; *SCO*, 1–4
VXT loader
changing the name of, *Overview*, 1–13
VXT loader file, *InfoServer*, 2–3; *OpenVMS*, 1–3
installing on host systems, *InfoServer*, 2–3
`vxtlpd` printer daemon, *ULTRIX*, 2–23, 2–24, 2–26; *OSF/1*, 2–21, 2–22, 2–24; *SunOS*, 2–21, 2–22; *HP–UX*, 2–15, 2–17; *AIX*, 2–21, 2–23; *SCO*, 2–19, 2–21
VXT manager password, *Managing*, 3–3
changing, *InfoServer*, 2–9
set during installation, *InfoServer*, 1–4
VXT printer support utilities, *ULTRIX*, 2–23; *OSF/1*, 2–21; *SunOS*, 2–21; *HP–UX*, 2–15; *AIX*, 2–21; *SCO*, 2–19
VXT software, *Overview*, 1–2
BOOT commands, *Appendixes*, A–1
booting and downloading, *InfoServer*, 2–3; *OpenVMS*, 2–3; *ULTRIX*, 2–3; *OSF/1*, 2–3; *SunOS*, 2–3; *HP–UX*, 2–3; *AIX*, 2–3; *SCO*, 2–3
overview, *Overview*, 1–9
booting terminals by Ethernet address, *InfoServer*, 2–6
default booting process, *Overview*, 1–11
files on CD–ROM, *OpenVMS*, 1–23
installation
See Installation

VXT software
installation (cont'd)
software subsets, *ULTRIX*, 1–3; *OSF/1*, 1–3; *SunOS*, 1–3; *HP–UX*, 1–3; *AIX*, 1–3; *SCO*, 1–3
loading
MOP, *OSF/1*, 2–7
with IP, *ULTRIX*, 2–3; *OSF/1*, 2–3; *SunOS*, 2–4; *HP–UX*, 2–4; *AIX*, 2–4; *SCO*, 2–3
with MOP, *ULTRIX*, 2–6
loading a specific version, *InfoServer*, 2–4
local clients, *Overview*, 1–16
network configurations, *Overview*, 1–3
network management overview, *Overview*, 1–1
overview, *Overview*, 1–1
purging, *InfoServer*, 2–7; *OpenVMS*, 1–14
removing
from UNIX systems, *Appendixes*, B–1
service names, *InfoServer*, 2–6
system images, *OpenVMS*, 1–3; *ULTRIX*, 1–4, 2–3; *OSF/1*, 1–5, 2–3; *SunOS*, 1–4, 2–3; *HP–UX*, 1–4, 2–3; *AIX*, 1–4, 2–3; *SCO*, 1–4, 2–3
creating directories for, *ULTRIX*, 2–3; *OSF/1*, 2–3; *SunOS*, 2–3; *HP–UX*, 2–3; *AIX*, 2–3; *SCO*, 2–3
naming conventions, *Overview*, 1–12
selecting, *OpenVMS*, 1–3; *ULTRIX*, 1–4; *OSF/1*, 1–4; *SunOS*, 1–4; *HP–UX*, 1–4; *AIX*, 1–4; *SCO*, 1–4
Version 2.1 features, *Overview*, 1–17
VXT system images
service names, *Overview*, 1–12

W

Window manager
customizing, *Managing*, 2–11
locking settings
for a work group, *Managing*, 3–26
Work group
backing up, *Managing*, 3–4
backing up customized settings, *Managing*, 3–38
change password, *Managing*, 3–43
choosing for configuration, *Managing*, 3–14
copying customized settings, *Managing*, 3–29
creating, *Managing*, 3–10
customization files
service ratings, *Managing*, 3–38
customizing, *Managing*, 3–20, 3–24
definition, *Managing*, 3–3
deleting, *Managing*, 3–45
Work group (cont'd)
finding for configuration, *Managing*, 3–16
for host-based terminals, *Managing*, 3–6
getting started, *Managing*, 3–2
locking customized settings, *Managing*, 3–24
locking DECterm settings, *Managing*, 3–25
locking window manager settings, *Managing*, 3–26
managing, *Managing*, 3–8 to 3–46
moving terminals to, *Managing*, 3–34
passwords
changing, *Managing*, 3–43, 3–44
policies, *Managing*, 3–5
specifying a password, *Managing*, 3–11
Unregistered Terminals work group, *Managing*, 3–3
Work group password
changing, *InfoServer*, 2–10
Work Group Settings button (CM), *Managing*, 3–23

X

X11R5 server, *Overview*, 1–17; *ULTRIX*, 2–13; *SunOS*, 2–13; *AIX*, 2–11; *SCO*, 2–12
`xdm` application, *ULTRIX*, 2–14; *OSF/1*, 2–14; *SunOS*, 2–14; *SCO*, 2–13
`xdm-config` file, *ULTRIX*, 2–15; *OSF/1*, 2–15; *SunOS*, 2–16; *AIX*, 2–15; *SCO*, 2–13
XDMCP support, *ULTRIX*, 2–14; *OSF/1*, 2–14; *SunOS*, 2–14; *HP–UX*, 2–12; *AIX*, 2–13; *SCO*, 2–13
customizing, *ULTRIX*, 2–14; *OSF/1*, 2–14; *SunOS*, 2–15; *AIX*, 2–14; *SCO*, 2–13
`xdm-errors` file, *ULTRIX*, 2–15; *OSF/1*, 2–15; *SunOS*, 2–15; *AIX*, 2–15; *SCO*, 2–13
`xdm-pid` file, *ULTRIX*, 2–15; *OSF/1*, 2–15; *SunOS*, 2–15; *AIX*, 2–15; *SCO*, 2–13
X font utilities
DEC OSF/1 AXP systems, *Appendixes*, B–3
ULTRIX systems, *Appendixes*, B–3
UNIX systems, *Appendixes*, B–3
XLFD font names, *ULTRIX*, 2–13; *OSF/1*, 2–13; *SunOS*, 2–13; *HP–UX*, 2–11; *AIX*, 2–12; *SCO*, 2–12

X logical font description, *ULTRIX*, 2–13; *OSF/1*, 2–13; *SunOS*, 2–13; *HP–UX*, 2–11; *AIX*, 2–12; *SCO*, 2–12
`Xreset` file, *ULTRIX*, 2–17; *OSF/1*, 2–17; *SunOS*, 2–17; *AIX*, 2–16; *SCO*, 2–15
`Xresources` file, *ULTRIX*, 2–15; *OSF/1*, 2–15; *SunOS*, 2–16; *AIX*, 2–15; *SCO*, 2–14
`Xservers` file, *ULTRIX*, 2–15; *OSF/1*, 2–14; *SunOS*, 2–15; *AIX*, 2–14; *SCO*, 2–13
X services, *ULTRIX*, 2–14; *OSF/1*, 2–14; *SunOS*, 2–14; *HP–UX*, 2–12; *AIX*, 2–13; *SCO*, 2–13
  DECnet transport, *OpenVMS*, 2–12
  LAT transport, *OpenVMS*, 2–11
  OpenVMS system, *OpenVMS*, 2–11
  requirements, *Overview*, 1–7
  TCPIP, *OpenVMS*, 2–12
`Xsession` file, *ULTRIX*, 2–16; *OSF/1*, 2–16; *SunOS*, 2–16; *AIX*, 2–16; *SCO*, 2–14
X session support
  overview, *Overview*, 1–7
`Xstartup` file, *ULTRIX*, 2–16; *OSF/1*, 2–16; *SunOS*, 2–16; *AIX*, 2–15; *SCO*, 2–14
XTDRIVER, *OpenVMS*, 2–11
X window session, *Overview*, 1–1
X Window System, *Overview*, 1–1

Y

`/ypwhich` command, *SunOS*, 2–6